

THE MX-5 WINDNET

FOR MK-2 MODELS



FOLLOWING PARTS ARE INCLUDED

ONE NET ASSEMBLY

ONE FIBRE-GLASS ROD

TWO BRACKETS, MARKED L AND R

TWO FLANGE SCREWS

REMOVE ATTACHING SCREWS ON LEFT OR RIGHT SIDE.
RIGHT SIDE IS SHOWN.



REPLACE THE UPPER SCREW WITH THE FLANGE SCREW FROM THE KIT.
ATTACH BRACKET, AND TIGHTEN SCREWS SLIGHTLY



PUSH BRACKET FORWARD, AND TIGHTEN THE SCREWS
ATTACH BRACKET ON OPPOSITE SIDE IN THE SAME WAY



FOLD OUT THE RODS ON THE NET ASSEMBLY, AND SLIDE ROD ENDS
INTO THE CONNECTING TUBES.



INSERT ONE END OF THE ROD INTO THE TUBE ON RIGHT OR LEFT HAND BRACKET. PUSH THE ROD ALL WAY DOWN TO STOP. BEND THE ROD,AND INSERT INTO OPPOSITE SIDE.



SPRAY THE NET EVENLY TOWARDS RIGHT AND LEFT SIDE. PULL THE ELASTIC BANDS AROUND THE BRACKET,AND ATTACH TO SNAP BUTTON. PUSH BANDS DOWN TO THE BEND OF THE ROD.



ATTACH LOWER PART OF NET TO THE EXISTING SNAP BUTTON.



IF YOUR BACKRESTS ARE FOLDED FAR BACK, THEY MIGHT TOUCH THE UPPER PART OF THE NET. IF THIS IS THE CASE, LOOSEN THE SCREWS AND FOLD THE BRACKETS BACKWARDS. TIGHTEN SCREWS.

